

Mounting instructions X518 for BMW R18

Our newly developed adapter can on the one hand be used as a mounting stand for the front and the rear of BMW R18. Moreover, it can also be used for our hydraulic lifting platforms. Oil change is not possible with this mounting stand.

Please pay attention to the following notes:

- No mounting while the exhaust system of your motorcycle is still hot – otherwise you risk getting burned at your hands or feet!
- Only use this product for the designated BMW motorcycle
- **Practice the following work steps with a second person for security reasons.**
- Only instructed people are allowed to work with and use this product.
- All work steps must only be done on solid and flat ground! No mounting on areas with slope.
- No maneuvering is possible with these casters, additional maneuvering sets can be ordered separately (item X518R2).
- The mounting stand must imperatively be removed before riding the motorcycle – otherwise there is a risk of falling!

How to mount the product:

- Screw the enclosed locating bolt M10 (No. 16) into the engine block (at the bottom, driving direction: right side) and tighten it firmly. This bolt will stay in the engine block.
- Connect the mounting frame with the two M10x85 SK screws. You can choose between two holes. Level 1 is for an easier jacking up process with lower elevation.
- Put the locking bolt (No. 17) into the adapter and counter with M10 nuts. Attention: Screw in as deep as possible to assure a secure snapping in the locating bolt (No. 16).
- At the beginning, the motorcycle is on its side stand. The rear part of adapter will be mounted at the holder of the exhaust system (driving direction: right side) and the front part of the adapter will be connected to the installed locating bolt (No. 16).
- Then, please go to the other side of the motorcycle (driving direction: left side), hold the motorcycle with the left hand and bring it into a horizontal position. Then, put the hand lever (No. 24) into the adapter.
- Now you can jack up the motorcycle with the hand lever (No. 24). It is helpful to position yourself as far at the back of the motorcycle as possible, this will facilitate the lifting process.
- To lift the motorcycle in the front, please use the enclosed adapter No. 18 (front part). This front part will be connected to the frame by means of the enclosed pin (No. 21).
- With the hand lever (No. 24) you can now lift the front of the motorcycle. Always pay attention that the pin really was inserted as deep as possible.
- The lowering of the vehicle is always done at the front first. Then you unhook the main adapter at the other side (driving direction: right side). Pull the locking bolt (No. 17).
- If you use a hydraulic lifting platform, please absolutely use the enclosed angles to assure a stable lifting process.
- No liability is taken if you are using lifting platforms which are not made by Kern-Stabi Motorradtechnik.