

Solorack

YAMAHA XV 950 / R

Artikel-Nummer:
600.4539 ohne Polster

Artikel-Nummer:
611.4539 mit Polster

Montage

Seitenkoffer
Topcases
Gepäckträger
Lock it System
Softbags
Aluminiumkoffer
Lederkoffer
Schutzbügel
Hauptständer
Chopper-Parts
Quad-Parts
Accessoires



Der Bausatz umfaßt die folgenden Teile:

611.4539 mit Polster

Stück	Bestellnr.	Bezeichnung
1	700008477	Solorack
1	700008487	Fahrer-Rückenlehne mit Polster
4	151.220	Kunststoffscheiben ø24 x ø8,5 x 2mm
2	150.891	Linsenkopfschrauben M8x25
2	150.923	Linsenkopfschrauben M8x30
4	150.995	U-Scheiben Ø8,4

600.4539 ohne Polster

Stück	Bestellnr.	Bezeichnung
1	700008477	Solorack
4	151.220	Kunststoffscheiben ø24 x ø8,5 x 2mm
2	150.891	Linsenkopfschrauben M8x25
2	150.923	Linsenkopfschrauben M8x30
4	150.995	U-Scheiben Ø8,4
2	151.116	Aludistanzen Ø18xØ9x5mm

Bild zeigt 611.4539 Solorack mit Polster



Solorack

YAMAHA XV 950 / R

Artikel-Nummer:
600.4539 ohne Polster

Artikel-Nummer:
611.4539 mit Polster

Montage

Seitenkoffer
Topcases
Gepäckträger
Lock it System
Softbags
Aluminiumkoffer
Lederkoffer
Schutzbügel
Hauptständer
Chopper-Parts
Quad-Parts
Accessoires



Vorbereitung:

Fahrer und Soziussitzbank abnehmen. Die beiden Halter der Soziussitzbank demontieren. An den nun frei zugänglichen Gewinden wird das Solorack verschraubt.

Befestigung vorne (Modell ohne Polster): ①

Mit den Linsenkopfschrauben M8x30 sowie U-Scheiben Ø8,4. Zwischen Solorack und Kotflügel die Kunststoffscheiben Ø24xØ8,5x2mm sowie die Aludistanzen Ø18xØ9x5mm fügen.

Befestigung vorne (Modell mit Polster):

Mit den Linsenkopfschrauben M8x30 sowie U-Scheiben Ø8,4. Zwischen Solorack und Kotflügel die Kunststoffscheiben Ø24xØ8,5x2mm. Rückenlehne zwischen Kotflügel und Solorack montieren - ohne Aludistanzen !

Befestigung hinten: ②

Gleich wie vorne mit den Linsenkopfschrauben M8x25, U-Scheiben ø 8,4. Zwischen Solorack und Kotflügel die Kunststoffscheiben Ø24xØ8,5x2mm fügen. Fahrersitzbank wieder montieren.



Anzugsmomente des Motorradherstellers beachten!

Nach der Montage alle Verschraubungen auf festen Sitz kontrollieren!
Bitte beachten Sie unsere beigefügten Serviceinformationen.

Weiteres lieferbares Zubehör:

C-Bow Packtaschenhalter	Nr. 630.4538
Lampenschutzgitter	Nr. 7004538
Motorschutzbügel	Nr. 5014538



Hepco & Becker GmbH
An der Steinmauer 6

D-66955 Pirmasens

Tel.: 06331 - 1453 - 100

Fax: 06331 - 1453 - 120

eMail: vertrieb@hepco-becker.de

www.hepco-becker.de

Solorack

YAMAHA XV 950 / R

Item-no.:
600.4539 without back rest

Item-no.:
611.4539 with back rest

Assembling instructions

Side cases
Top cases
luggage frames
Lock it system
Softbags
Aluminium luggage
Leather luggage
Protection bars
Center stands
Chopper parts
Quad parts
Accessories



The kit includes the following parts:

611.4539 with back rest

Quant	item no.	description
1	700008477	Solorack
1	700008487	Drivers Back rest
4	151.220	plastic washer $\varnothing 24 \times \varnothing 8,5 \times 2\text{mm}$
2	150.891	filister head screws M8x25
2	150.923	filister head screws M8x30
4	150.995	washer $\varnothing 8,4$

600.4539 without back rest

Quant	item no.	description
1	700008477	Solorack
4	151.220	plastic washer $\varnothing 24 \times \varnothing 8,5 \times 2\text{mm}$
2	150.891	filister head screws M8x25
2	150.923	filister head screws M8x30
4	150.995	washer $\varnothing 8,4$
2	151.116	alu spacer $\varnothing 18 \times \varnothing 9 \times 5\text{mm}$

Picture shows 611.4539 Solorack with backrest



Solorack

YAMAHA XV 950 / R

Item-no.:

600.4539 without back rest

Item-no.:

611.4539 with back rest

Assembling instructions

Side cases

Top cases

luggage frames

Lock it system

Softbags

Aluminium luggage

Leather luggage

Protection bars

Center stands

Chopper parts

Quad parts

Accessories



Preparing:

Remove driver and passenger seat . Dismantle the two holders of the passenger seat.

At the now freely threads the solorack will be screwed.

Fastening front (Model without back rest): ①

with filister head screws M8x30 and washer Ø8,4. Add plastic washer Ø24xØ8,5x2mm between Solorack and fender and the Alu spacer Ø18xØ9x5mm.

Fastening front (Model with back rest):

with filister head screws M8x30 and washer Ø8,4. Add plastic washer Ø24xØ8,5x2mm between Solorack and fender. The back rest will be add between Solorack and fender - without the alu spacers.

Fastening rear: ②

with filister head screws M8x25 and washer Ø8,4. Add plastic washer Ø24xØ8,5x2mm between Solorack and fender. Mount drivers seat again.



Control all screw connections after the assembling for tightness!

Please notice our enclosed service information.

Also available:

C-Bow leather bag holder

Item-no.: 630.4538

Engine guard

Item-no.: 5014538

Headlight grilles

Item-no.: 7004538



Hepco & Becker GmbH
An der Steinmauer 6
D-66955 Pirmasens
Germany

Tel.: +49 6331 - 1453 - 100

Fax: +49 6331 - 1453 - 120

eMail: vertrieb@hepco-becker.de

www.hepco-becker.de