

ALU RACK KTM LC8 950 SM ALU RACK KTM LC8 950 SM

Montagehinweise

Alle vom Motorrad gelösten Schrauben sind gemäß Herstellerangaben wieder zu montieren, oder mit von SW-MOTECH gelieferten Schrauben zu ersetzen. Falls nicht anderweitig definiert, diese Schrauben nach Tabelle anziehen.

M6	9,6 Nm
M8	23 Nm
M10	46 Nm

Gegebenenfalls Schrauben mit flüssiger Schraubensicherung einkleben. Prüfen Sie nach 50 km alle Verbindungen auf festen Sitz.

Max. Zuladung 7,5 Kg inklusive Koffer und Adapter. Ist das Zuladungsgewicht des Fahrzeuges durch den Hersteller limitiert, gelten diese Grenzwerte.

! Achtung: Falls die Montage einer Adapterplatte vorgesehen ist, **MÜSSEN** die Haltenocken am Alu-Rack vor dessen Anbau am Motorrad verschraubt werden.

Attention: Cam-locks from adapter kit **MUST** be installed before attaching the alu-rack to the bike.

SW-MOTECH GmbH & Co. KG
Bahnhofstrasse 44d
35282 Rauschenberg
-Germany-

Tel.: ++ 49 (0) 6425 816 800
Fax: ++ 49 (0) 6425 816 810

www.sw-motech.com

GPT.04.526.100
Revision: 00

Mounting Instruction

SW-MOTECH products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. SW-MOTECH takes no responsibility for damages caused by improper installation.

All screws, bolts and nuts, including all replacement hardware provided by SW-MOTECH, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M6	9,6 Nm
M8	23 Nm
M10	46 Nm

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Loctite") should be used to secure all screws, bolts and nuts.

Max. Load On Rear Carrier: 7,5 Kg (16,5 lbs) inclusive case and adapter or the motorcycle manufacturer's weight limit, whichever is less.

Distanzbuchse (4) entfällt in Verbindung mit SW-MOTECH Kofferträger (KFT.04.266.100).

Spacer (4) is not applicable in connection with SW-MOTECH side carrier (KFT.04.266.100).

1 Alu Rack
Alu Rack



schwarz/black
GPT.04.526.001 02
Anzahl/ Pcs. 1

5 Anbaublech
Fixing Lug



schwarz/black
GPT.04.526.002 00
Anzahl/ Pcs. 1

6 Senkkopfschraube
Counter Sunk Screw



schwarz/black
M8 x 30 DIN 7991
Anzahl/ Pcs. 2

7 Senkkopfschraube
Counter Sunk Screw



schwarz/black
M8 x 16 DIN 7991
Anzahl/ Pcs. 2

2 Senkkopfschraube
Counter Sunk Screw



schwarz/black
M8 x 60 DIN 7991
Anzahl/ Pcs. 2

3 Distanzbuchse
Spacer



Da:20 Di:8,4 h:22
Anzahl/ Pcs. 2

4 Distanzbuchse
Spacer



Da:20 Di:8,4 h:5
Anzahl/ Pcs. 2

