



Fitting Instruction

Article-No. : 150A015
Product : Tour Match Kit
Model : Aprilia RSV 1000R 2006 - 2009
Type : RR

Important:

Read this instruction manual carefully and mind all warnings and tips. You should do this work only if you're qualified; otherwise we recommend this mounting to be done by a qualified workshop. Improperly mounting of this kit can reduce the driveability of the motorcycle and may be a risk to your health and life.

Special works are marked with the following signs. Please take special care on these works.



Warning! Important mounting instruction. It shows risks to your life and health.



Tips for mounting and maintenance or to avoid damage.

Fitting:

Mounted conversion kit



i The battery ground should be disconnected before working on electric wiring and switches!



Remove brake-hose(s). **Caution:** avoid brake fluid on painted surfaces! **Any work on the brake system or bleeding the system should be done by an authorized dealer or a qualified mechanic!**

Remove handlebar controls, clutch lever bracket and brake cylinder assy, then remove the original handlebar.

i **Assure that the front wheel is free from any load when dismantling top yoke!**

Remount top yoke together with both Tour Match clamps as one unit. To fix top yoke, first tighten steering head nut up to 15Nm / 11lbf ft, then fix the slider tube clamp bolts. Now tighten steering head nut up to the required torque, tightening torques refer to the vehicle manufacturer's instruction.



Push Match clamps up towards the top yoke, align them and tighten them slightly. Now install the tubes using M6x22 and tighten these bolts with 10Nm (7.31lbf ft).

Fairing: The fairing needs to be lifted up by fitting rubber spacers (Ø6xØ25x6) between mirror support and fairing. Dismount mirrors, fit the rubber spacers and remount mirrors with the attached self-locking nuts M6. Use mounting assy with P/N 156A015.4.

Reroute throttle cables according to the instructions underneath first. Then you should check the clearance to the tank and fairing, therefore you have to mount all controls provisorily on the clip-on. **It's important to mount and align the controls in a way that the tubes project out of the grips by 10mm.** Adjust clip ons by turning the Match clamps on the slider tubes, then tighten the bolts M6x25 with 10Nm (7.31lbf ft). Now drill the bores for the controls and fix them finally. The left grip should be installed with glue. Fit new reservoir bracket into the tube and mount reservoir with M6x14 and washer.



Throttle cables: Reroute left from steering head, as shown and fix them with bracket and clamp. The bracket's weld nut as well as the clamp faces downward. Fix tank with rubber spacers (Ø8.5 x Ø25 x 6), stepped bushings and bolts M6x40. Use mounting assy with P/N 156A015.3. Check throttle cable for free movement on every steering angle.






Brake hose: Mount attached brake hose with new seal rings and route as original. **Mind the mounting instructions that are delivered with the brake hose.** Fit right reservoir as shown using mounting assy with P/N 156A015.2.



Clutch hose: Routing remains unchanged. Fit left reservoir as shown using mounting assy with P/N 156A015.1.



Wiring harnesses: Route as original.



Make sure that no cable, hose or harness is bended and stays tension-free over the whole steering angle.

The conversion kit is now completely mounted. Always check local laws and your manufacturer's warranty conditions for using aftermarket parts on your bike!

Ride safe and have fun!



LSL-Motorradtechnik GmbH • D-47809 Krefeld

www.lsl.eu