

MOTOPLASTIC, S.A.

Molí de la sal, 1 - 08403 Granollers (Barcelona) SPAIN

Tel. 34 93 849 06 33 - Fax 34 93 849 09 88

info@puig.tv - info@puigusa.com

www.puig.tv - www.puigusa.com

Ref.: 7013

INSTRUCCIONES DE MONTAJE - MOUNTING INSTRUCTIONS - MONTAGEANLEITUNG

**CARENABRÍS ADAPTABLE A – WINDSHIELD FOR – SCHEIBE FÜR
DUCATI MONSTER 821-1200**



ID.	PIEZA / PART	DESCRIPCIÓN	DESCRIPTION	QTY.
1		Carenabrís	Windshield	1
2		Soporte metálico derecho	Right metal support	1
3		Soporte metálico izquierdo	Left metal support	1
4		Casquillo Ø int. 8 x Ø ext. 13x15	Ø inner 8 x Ø outer 13x15 arrowhead	2
5		Tornillo Allen M8x45 DIN 912	M8x45 DIN 912 Allen screw	2
6		Silemblock M5	M5 Silemblock	4
7		Tornillo Allen M5x16 ISO 7380	M5x16 ISO 7380 Allen screw	4
8		Arandela nylon M5x0,5	M5x0,5 nylon washer	4

MOTOPLASTIC, S.A.

Molí de la sal, 1 - 08403 Granollers (Barcelona) SPAIN

Tel. 34 93 849 06 33 - Fax 34 93 849 09 88

info@puig.tv - info@puigusa.com

www.puig.tv - www.puigusa.com

Ref.: 7013

INSTRUCCIONES DE MONTAJE - MOUNTING INSTRUCTIONS - MONTAGEANLEITUNG

**CARENABRÍS ADAPTABLE A – WINDSHIELD FOR – SCHEIBE FÜR
DUCATI MONSTER 821-1200**

