
scalarider®Oz

his Quick Guide is not a substitute to the user manual and addresses only a limited scope of features and functions of your scala rider Qz. This reference guide may be useful to look up some basic functions and commands while you are on the road and may not have access to the

This Quick Guide can be printed and folded for easy reference, or it may be viewed directly on your smartphone.



¹ GENERAL FUNCTIONS	
Power ON / OFF	Press (a) for 2 seconds ON: 3 BLUE flashes + Ascending tone OFF: 3 RED flashes + Descending tone
Volume	Tap ② or ○ to adjust and set volume of current audio source
Mute	Tap ⊕ and © simultaneously
Battery Check	In Standby, press
Enable/Disable Spoken Status Announcements (Enabled by default)	Via the Cardo Community

² STATUS LIGHTS	
None	scala rider is OFF
1 BLUE flash every 3 seconds	Standby mode No active audio sources
2 BLUE flashes every 3 seconds	Active mode – Call in progress / music or other audio source is ON
1 RED flash every 3 seconds	Standby mode – Battery is low
2 RED flashes every 3 seconds	Active mode – Battery is low
Solid RED	Charging

³ VOICE CONNECT (VOX)		
VOX Activation	Speak any word loudly into the microphone	
Answer a call	Speak any word loudly into the microphone	
Reject a call	Remain silent for about 15 seconds	
VOX Sensitivity (Default: Regular)	Adjust via the Cardo Community. High: Use this setting if it is difficult to activate VOX Low: Use this setting if it is too easy to activate VOX	

4 PAIRING BLUETOOTH DEVICES: MOBILE PHONE/ GPS/A2DP MUSIC PLAYER	
Bluetooth Channel 1 pairing mode	In Standby, press O for 5 seconds
Bluetooth Channel 2 pairing mode	In Standby, press 🗢 for 5 seconds

⁵ MAKING AND RECEIVING PHONE CALLS		
Answer a call	Tap ③ or say any word loudly to answer by VOX	
Reject a call	Remain silent for 15 seconds, or press and hold 1 for 2 seconds	
End a call	Тар 🔊	
Voice Dial* (if supported by mobile phone)	Tap and simultaneously and follow the prompt from the mobile	
Redial*	Press 🖸 and 🌑 for 2 seconds	
Hot-Dial**	Tap 1 three times	
Set default phone***	When on a phone call, press O for 5 seconds	
Toggle default phone***	In Standby, press 🖸 for 5 seconds	

- *This feature is not available during mobile calls
- ** To use the Hot-Dial feature, first configure the number via the Cardo
- *** If you have 2 mobile phones paired directly to your scala rider, you will need to set one of them to use as default for outgoing calls.

6 LISTENING TO MUSIC VIA A2DP	
Play	In Standby, tap 🖸
Pause/Stop	Press 1 for 2 seconds
Next Track	With music ON, tap
Previous Track*	With music ON, double tap 🛐

*With some mobile phones you may need to repeat this action

7 TROUBLESHOOTING	
Reboot	If your scala rider stops responding, reset it by turning it off and then on again (press b for 2 seconds).
Reset Pairing (Deletes all paired devices)	 In Standby, press for 5 secs until LED flashes RED/BLUE. Press for 2 seconds until LED flashes 5 times in PURPLE.

The contents of this Quick Guide, including all text, illustrations and drawings are the exclusive intellectual property of Cardo Systems, Inc. (the "Company") and are protected by copyright laws. Any partial or total reproduction, translation and or dissemination, without the prior written authorization by the Company are strictly prohibited. Any rights not expressly granted herein are reserved.