


SIZE CHART EASY AIR PRO



S	M	L	XL	2XL	3XL
A - 45.10 cm	A - 46.30 cm	A - 47.50 cm	A - 49.00 cm	A - 50.50 cm	A - 52.00 cm
B - 50.50 cm	B - 53.00 cm	B - 55.50 cm	B - 58.50 cm	B - 61.50 cm	B - 64.50 cm
C - 65.70 cm	C - 67.10 cm	C - 68.50 cm	C - 70.25 cm	C - 72.00 cm	C - 72.75 cm
D - 63.50 cm	D - 65.75 cm	D - 68.00 cm	D - 70.25 cm	D - 72.50 cm	D - 74.75 cm

A - BACK SHOULDERS WIDTH

The shoulders size must be measured in the back. It is the measurement from the tip of one shoulder to the other.

B - CHEST WIDHT

The chest size must be measured by passing the meterstick under the armpits. The chest widht is the mesasurement of the cheast largest part.

C - SLEEVE LENGHT

The sleeve lenght is the measurement from the shoulder to the wrist

D - FRONT LENGHT

The front lenght is the measurement from the neckline shoulder cut to the waistband