## 6.4\*10 cm



Your new resettable combination padlock is preset at 0-0-0-0.(Even though dials may appear in other numbers.)

To reset the combination:

Step 1 Leave the dials at preset combination 0-0-0-0 and pull out the shackle.

Step 2 Turn the shackle counterclockwise to 90° and press down all the way.

Step 3 Keep holding the shackle and set the dials to your own desired combination.(Do not let go of the shackle while setting the dials.)

Step 4 Release the shackle and return to its original position. Your lock is now ready to open at your own personal combination.

Keep your combination in a safe and accessible place for future reference.

