

Visor for helmet model Probiker® Demi-Jet Fiber/Demi-Jet Fiber 2/Demi-Jet Fiber 2 LED

Dear Customer, Thank you for placing your trust in our product.
Please use these instruction when changing the helmet visor. The Louis Team wishes you lots of fun.

Changing the helmet visor

Be sure to place your helmet on a soft, non-slip surface while you work to prevent it from getting scratched or otherwise damaged.

If you have any difficulties or questions while changing the visor, stop working on the helmet or visor before it gets damaged. Consult the vendor or the Louis Technical Centre by fax on +49 (0) 40 734 193 58 or by e-mail for reliable advice: technikcenter@louis.de. That way, you can help Louis help you ensure that your visor is changed properly.

1. Flip up the visor fully (Fig. 1).
2. Flip up the lock (Fig. 2) of both visor mechanisms fully. When open, the lock must be perpendicular to the helmet. With one hand, gently press the visor against the helmet right beside the visor mechanism; with the other hand, grip the open lock and turn it slowly 90 degrees towards the front of the helmet until you feel resistance (Fig. 3). Now remove the lock mechanism (Fig. 4). Repeat these steps for the other side of the helmet. Afterwards, you can remove the old visor.
3. Place one side of new visor as if "fully open" onto the mechanism in the same lock position and press it gently against the helmet (Fig. 5). Replace the lock mechanism such that the flip-up lock faces up and turn it towards the back of the helmet (Fig. 6) until you feel it engage. Flip down the lock. Repeat these steps for the other side of the helmet.

Visor replacement is now complete. Check again that the visor is sitting well in the grooves and engages perfectly before you use your helmet again. The visor should not slip out of the guides when you flip it up and down.

